Algoritma

Error Helper

Algoritma DSS: Data Engineering in Python using Airflow


Bagaimana menentukan path yang tepat ke database dan data input? (Untuk tahapan 3 Section "Move Code to Airflow Project" di 2_DSS_Airflow.html)

- 3. Buka VSCode di folder airflow. Kemudian sesuaikan path db , report dan data_input_airflow di dalam .py . Contoh:
 - Fungsi fetch_clean() -> files = glob.glob("/home/irfancr/airflow/dags/data_input_airflow/*.csv")
 - Fungsi db_to_db() -> database = '/home/irfancr/airflow/dags/db/transactions.db'
 - Fungsi report_generator() -> with pd.ExcelWriter(f'/home/irfancr/airflow/dags/report/{periode}.xlsx') as writer:

```
v def fetch_clean():
    files = glob.glob("/home/irfancr/airflow/dags/data_input_airflow/*.csv")
    print(f"files: {files[0]}")
```

Tahapan:

- Buka vscode pada folder airflow (bagi Windows, silahkan masuk melalui \\wsl\$ di folder manager)
- Buka terminal (bagi Windows, buka terminal WSL)



 Jalankan command pwd, Anda akan mendapatkan path folder airflow Anda (pada kasus ini: /home/irfancr/airflow)

```
PROBLEMS 3 OUTPUT DEBUG CONSOLE TERMINAL PORTS

irfancr@DESKTOP-5P4CFUE:~/airflow$ pwd
/home/irfancr/airflow
irfancr@DESKTOP-5P4CFUE:~/airflow$
```

 Silahkan sesuaikan path untuk keseluruhan database, file input atau export excel. (Pada kasus ini: /home/irfancr/airflow/dags/...)

```
3. Buka VSCode di folder airflow. Kemudian sesuaikan path db , report dan data_input_airflow di dalam .py . Contoh:
```

- Fungsi fetch_clean() -> files = glob.glob("/home/irfancr/airflow/dags/data_input_airflow/*.csv")
- Fungsi db_to_db() -> database = '/home/irfancr/airflow/dags/db/transactions.db'
- Fungsi report_generator() -> with pd.ExcelWriter(f'/home/irfancr/airflow/dags/report/{periode}.xlsx') as writer:

Isi folder /home kosong di dalam \\wsl\Ubuntu\

Jika folder /home kosong, ini dikarenakan Anda masih dalam mode `root`. Silahkan ikuti tahapan berikut untuk mendapatkan folder airflow:

- Buka terminal Ubuntu
- Jalankan command Is

```
root@DESKTOP-5P4CFUE:~

root@DESKTOP-5P4CFUE:~# 1s

snap

root@DESKTOP-5P4CFUE:~# pwd

/root

root@DESKTOP-5P4CFUE:~#
```

Jika hasil /root, maka Anda masih terdapat pada proses root dan belum membuat user di Ubuntu.

 Silahkan jalankan command berikut dan mengikuti tahapan pembuatan user dengan command berikut

sudo adduser <your_name>

Note: <your_name> silahkan diubah sesuai keinginan, pada kasus ini menjadi trialuser

```
root@DESKTOP-5P4CFUE:~# pwd
/root
root@DESKTOP-5P4CFUE:~# sudo adduser trialuser
Adding user `trialuser' ...
Adding new group `trialuser' (1001) ...
Adding new user `trialuser' (1001) with group `trialuser' ...
Creating home directory `/home/trialuser' ...
Copying files from `/etc/skel' ...
New password:
Retype new password:
Sorry, passwords do not match.
passwd: Authentication token manipulation error
passwd: password unchanged
Try again? [y/N] y
New password:
Retype new password:
passwd: password updated successfully
Changing the user information for trialuser
Enter the new value, or press ENTER for the default
        Full Name []: trial user
        Room Number []: 000
        Work Phone []: 000
        Home Phone []: 000
        Other []: 000
Is the information correct? [Y/n] y
```

 Silahkan masuk ke mode user dengan command sudo su <your_name> dan dilanjutkan cd ~

```
root@DESKTOP-5P4CFUE:~# sudo su trialuser
trialuser@DESKTOP-5P4CFUE:/root$ cd ~
trialuser@DESKTOP-5P4CFUE:~$
```

 Silahkan jalankan tahapan Preparing Python & Virtual Environment hingga tahapan terakhir pada [Updated] Algoritma Handbook - Python Installation.pdf

Dss_dag tidak terlihat pada webserver airflow

Credit tips for Pak Ronnie: Reference https://github.com/teamalgoritma/community/discussions/910

- Check home airflow dengan cara echo \$AIRFLOW_HOME, jika kosong maka,
- Set \$AIRFLOW_HOME, dengan tahapan
 - Cari folder airflow di komputer Anda, setelah masuk, jalankan command pwd

```
irfancr@DESKTOP-5P4CFUE: ~/airflow

irfancr@DESKTOP-5P4CFUE: ~$ ls

airflow airflow_env hello_world_dag.py training_model_dag.py

irfancr@DESKTOP-5P4CFUE: ~$ cd airflow

irfancr@DESKTOP-5P4CFUE: ~/airflow$ pwd

/home/irfancr/airflow

lirfancr@DESKTOP-5P4CFUE: ~/airflow$ ____
```

Path hasil pwd adalah directory airflow Anda

- b. Jalankan export AIRFLOW_HOME=<PATH_AIRFLOW_ANDA> (Pada kasus di atas, akan menjadi: export
 AIRFLOW_HOME=/home/irfancr/airflow)
- Jalankan airflow db migrate
- Buat account untuk airflow
- Silahkan section Move Code to Airflow Project pada bagian bawah file
 2_DSS_Airflow.html hingga selesai.